

# Replacing Old Skin Fittings with TruDesign

## Tools

- Wooden plug, as used in Marine Safety for emergency hole filling (or similar) – see below.



- Hole saw the same size as the existing skin fitting (Thru Hull) external diameter. Or if you want to replace with larger skin fitting (Thru Hull) - hole saw same size as new skin fitting (thru Hull) external diameter.
- Drill and Handsaw

## Taking the old fitting out

- Place a suitable sized plug into the old skin fitting (Thru Hull) and hand saw off.



## Taking the old fitting out – continued

- Mark the centre of the plug, then (with the hole saw) drill the old fitting out.



- Remove the old skin fitting (Thru Hull) head.
- Clean surface of old paint debris, then install TruDesign Skin Fitting (Thru Hull) as per separate Product Information Sheet – see our web site <https://www.trudesign.nz/marine/products/20-skin-fittings-domed>

